

PB BENCH LINES AND PCB LABSTATIONS

PCB500S, PCB520S, PB710, PB710S, PB720 AND PB720S

INSTALLATION

1. Carefully consider where the unit will be located. It should be close to any necessary services

2. Remove unit and ancillary items from the packaging. If fitted, remove plastic protective film from white side panels of the base unit. Ensure the following parts are included:

Ensure all water services are connected in accordance with local water bylaws. Minimum pressure of water inlet for spray wash tanks should be 2 bar.

Description	500	520	710	720
Lid/Basket	3	3	4	4
32mm Bend	1	1	1	1
Water Inlet Tap	2	2	1	1
Washing machine hose	2	2	1	1

3. Connect spray wash water inlet to water supply via washing machine hose and threaded washing machine type tap, designed to fit standard 15mm copper cold water mains pipe by means of a compression joint. Waste water outlet to mains waste is via the 32mm push fit bend.

4. **Before connecting to mains power ENSURE ALL HEATED TANKS ARE FILLED WITH LIQUID TO 5 – 10mm below the shoulder on which the lid rests. NEVER TURN ON ANY TANK WHEN IT IS EMPTY.**

Always use a Power Cut-Out (RCD) device. Please read electrical safety notice on reverse (or attached) insert plug into 13amp socket. Turn on the mains switch on the front of the unit and ensure it illuminates to confirm power is on.

Each heated processing tank's operating temperature has been factory set as follows

PCB500/PCB520

Developing Tank 25°C

Etching Tank 45°C

Immerse Tin Tank 50°C **

PCB710/PCB720

Developing Tank 25°C

Etching Tank 45°C

Resist Strip Tank 45°C

Immerse Tin Tank 50°C **

**** The immerse tin tank is set for 50°C as the tin powder has to be dissolved in water of that temperature. Once this is done the heater to this tank should be turned off and the tin used at room temperature**

Selecting PCB Chemistry

Mega PB process tanks are designed specifically for use with Mega's range of PCB chemistry. The carefully selected range of compatible chemistry has many safety features. The developer does not, unlike others, contain Sodium Hydroxide (Caustic Soda) and a recent report by an occupational hygienist concluded that, under the test conditions, **NO LOCAL EXHAUST VENTILATION IS REQUIRED** using Mega's PCB chemistry and tanks. Copies of the report are available upon request.

For etching Copper & Brass please dilute (600-015 or 600-016) with 1.5 litres water and 3.5 litres Ferric Chloride for Stainless Steel use as supplied.

The following chemistry, available from Mega is recommended:

NB PCB520 & PCB720 have 10 litre tanks.

Developer	600-010	1 litre Conc. (10 litres)
Etchant	600-015	Liquid Etchant (5 Litres)
Etchant	600-016	Liquid Etchant (25 Litres)
Fine Etch	600-014	Fine Etch Crystals (5 litres)
Stripper	600-019	Resist Strip 1 litre =(5 litres)
Tin	600-021	Immerse Tin 450g=(5 litres)

Instructions on Use

The combined lid and basket holder enables the operator to move the PCB laminate into a separate or integral spray wash tank for cleaning without coming into contact with the chemistry.

Processing Times:

The time the board is left immersed in a process tank should be determined from the relevant chemical processing instructions. As a guide, developing normally takes 30 – 60 seconds, etching 5 – 6 minutes, resist stripping 2 – 3 minutes and tinning 5+ minutes.

Spray Wash:

Boards should be washed in a spray wash tank for at least 60 seconds. The spray wash tanks have a solenoid valve operated by an illuminated switch on the control panel. When the switch is on water is forced out of the two spray wash bars at the top of the tank.

Etching:

The etch tank has an integral air pump operated from the front control panel. **Do not operate the pump unless a lid / basket are fitted on the tank.** For optimum results panels should be inverted half-way through the etching cycle.

Fault Finding:

If you have a problem with your unit – Check the following:- If the problem persists, please contact Mega's repair department quoting the model number and serial number of your unit..

Problem	Solution
No power to the tank, mains switch does not light up.	Check fuse in the tank and mains plug.
Heater light to Developing tank does not light up.	Check that room/water temperature is not already close to 25°C
Heater light is on, but liquid does not heat up.	Contact Mega.
Liquid becomes too hot.	Check liquid level. It should be 5 – 10mm below top of tank

Servicing and Spares

Before cleaning or servicing any tank ensure the power is switched off and the mains cable is removed.

Each time the chemistry is changed, clean and rinse the tank before replenishing.

Ferric chloride (Etchant) stains can be removed with Mega's Ferric Cleaner (Part No. 600-039).

The following common spare parts can be ordered:

160032	Heater
160056	Thermostat
167004	Amber Indicator
167111	Green Latching Switch
167112	Yellow Latching Switch
291000	Bubble Bar Assembly
900-041	Lid / Basket 12" x 18"

Electrical Safety Notice

CONNECTIONS TO MAINS ELECTRICAL SUPPLY

This equipment is designed to safety class 1

Before connecting this equipment to the mains electricity supply, examine the information on the apparatus rating label.

Ensure that the mains supply is single phase alternating current (a.c.) of the stated frequency (Hz), with neutral nominally at earth potential.

Check the supply voltage is within the stated range.

The equipment rating label states the value of the fuse fitted to the apparatus itself. Ensure that the plug or supply circuit is fitted with an appropriate fuse of higher value.

WARNING THIS APPARATUS MUST BE EARTHED.

The wires in the mains lead are coloured in accordance with the following code:

Green/Yellow - Earth (E)

Blue - Neutral (N)

Brown - Live (L)

If a moulded fused plug is not fitted connect the wires to a non-reversible 3 pin plug as follows:-

Green/Yellow wire to terminal marked: E (earth) or G (ground) or coloured Green or coloured Green/Yellow.

Blue wire to terminal marked: N (neutral) or Common or coloured blue.

Brown wire to terminal marked: L (live) or Phase or coloured Brown.

NO SERVICING OR MAINTENANCE SHOULD BE CARRIED OUT UNTIL THE UNIT HAS BEEN SWITCHED OFF AND ISOLATED FROM THE MAINS ELECTRICITY SUPPLY.

Any spare parts which may be required are supplied on the understanding that the replacement of these requiring the exposure of live electrical connections will be undertaken by an electrically qualified person.



Mega Electronics Limited

Mega House, Grip Industrial Estate, Linton, Cambridge, CB21 4XN. England.

Telephone: +44 01223 893900 Fax: +44 01223 893894

email: sales@megauk.com web: www.megauk.com