

# INSTRUCTIONS FOR USE OF DRY FILM

## PLEASE NOTE:

**\*\*\* Handle with care, only use in safe light conditions \*\*\*\***

### Lamination

1. Load the rollers,
2. Press Button '125' and wait until 'READY' flashes on the main display.
3. Feed a small amount of film through the rollers by pressing the 'RUN' button. (This is done to avoid any affected film from the hot rollers processed to laminate board further by again pressing the 'RUN' button.
4. When board is clear of rollers – STOP rollers and trim board with a sharp knife.

### Exposure

Using a Mega AZ220 Exposure Unit, set timer for '17 seconds' (this can vary depending on your unit / artwork)

### Developing (Remember to remove clear protective film)

Using a Mega develop tank ; Place board in tank at room temperature 30°C – 35°C for two minutes, then move basket up and down in tank until image appears.

Using a Mega Jet Etcher: Place the board in tank using supplied Holder at room temperature 25°C – 30°C. Develop for one – two minutes depending on artwork.

### Storage

This product must be stores in a suitable black bag and box.  
Shelf life of this product is 12 months.



**MEGA ELECTRONICS LIMITED.,**  
Mega House, Grip Industrial Estate,  
Linton, Cambridge. England. CB21 4XN  
Tel: +44 (0) 1223893900 Fax: +44(0) 1223 893894  
email: [sales@megauk.com](mailto:sales@megauk.com) web: [www.megauk.com](http://www.megauk.com)