



REPLACING TUBES AND STARTERS GENERAL

1. Disconnect mains supply before carrying out any form of Maintenance.
2. Remove the screws from the frame retaining the glass or Mylar film, remove the frame and glass from the unit, taking care not to mark the reverse face of the glass with fingerprints etc.

NOTE: Where gas struts are fitted it is necessary to unfasten them from the top only. Use suitable tools to unscrew and remove the pivot pin, then use a hexagon socket driver to remove the gas strut bracket from the top. It is advisable to support the top against a perpendicular surface. Care should be taken to protect the painted surfaces.
3. With frame and glass / Mylar removed, the tubes and starters are now accessible. Twist the tubes through 90 degrees and then lift them clear of their holders. Twist and unplug the starters from their holders.
4. Re-assemble in reverse order (as above), taking care not to damage or mark the surfaces of the glass or Mylar film. If necessary, clean with a damp cloth.
5. When testing, do not view the illuminated tubes from a close distance for an extended period.



MEGA ELECTRONICS LIMITED.

Mega House, Grip Industrial Estate, Linton, Cambridge England. CB21 4XN
Telephone: +44 (0) 1223 893900 Fax: +44 (0) 1223 893894
email: sales@megauk.com web: www.megauk.com